

RT30 Hand transmitter

PULSE | UP/STOP/DOWN



The RT30 hand transmitter is designed for universal use. It can be used together with any Easywave receiver and in any of the operating modes available.

It may be used to control roller shutters for example or, more generally, to switch electrical devices on or off.

An easily visible LED lights up when the battery needs to be changed.




RT30E5001-01-22K

RT30E5004-01-02K


Technical specifications

Coding	Easywave
Frequency	868.30 MHz
Channels	1 or 4
Range	typically 150 m in good free-field conditions
Power supply	1x 3V-battery, CR2032
Operating indicator	LED
Operation	transmission lasts as long as the button is pressed (maximum 36 seconds)
Operating temperature	-20 °C to +60 °C
Dimensions (W/L/H)	38/60/14 mm (without wall holder)
Weight	25 g (including battery)
Color	glossy white similar RAL 9003 glossy black similar RAL 9005

Models



RT30E5001-01-xxK
1x UP/STOP/DOWN



RT30E5004-01-xxK
4x PULSE

Scope of delivery

- Hand transmitter incl. battery
- Wall holder
- Adhesive pad
- Operating manual

Accessories (optional)

- | | |
|-----------------|---------------------------|
| RT30-ACC-03-02P | Wall holder, glossy white |
| RT30-ACC-03-22P | Wall holder, glossy black |



RT30-ACC-03-02P



RT30-ACC-03-22P

Models

Product number	Description
RT30E5001-01-02K	Hand transmitter, Easywave, 1x UP/STOP/DOWN, glossy white
RT30E5001-01-22K	Hand transmitter, Easywave, 1x UP/STOP/DOWN, glossy black
RT30E5004-01-02K	Hand transmitter, Easywave, 4x PULSE, glossy white
RT30E5004-01-22K	Hand transmitter, Easywave, 4x PULSE, glossy black